



ELITE LINE INTERNATIONAL CO., LTD.

6F, No. 59, Changjiang St., Chianjen Chiu, Kaohsiung 806, Taiwan R.O.C..

Tel No. : 886-7-331-1060

Fax No. : 886-7-331-0100

<http://www.watervalve.com.tw>

The Installation of Water Hammer Arresters:

- Before installation, make sure the pipeline pressure is not lower than the pressure inside the air chamber that is 2.5 kgf/cm².
- Maintain the pressure inside water hammer arrester air chamber at 60% ~ 90% of pipeline pressure to get the best effect.
- If the pipeline water pressure or air chamber pressure gets lower, please pump more air or release air from the air-pumping hole at the top of the arrester.
- Vertical, horizontal and upside-down installation ways are acceptable.

